



**Part Number:** ACS-703-IC

## ICON Golf Cart **Inner** **Basket Fits 2019-2023**

**Includes:** Inner Basket & Mounting Hardware



**Note:** This installation method uses 4 self tapping screws. Your hardware kit may have additional hardware that will not be used in this install.

**Step 1:** Align basket roughly 1 inch above existing nuts that hold the windshield in place. Using a Clamp hold the basket in place and repeat on the opposite side. make sure the basket is level and Aligned at a comfortable position. **Do not remove the bolts (existing hardware) from the windshield.**



**Step 2:** Using a 8mm socket & drill, install one self-tapping on each side of the basket.

**Step 3:** Using a 8mm socket & drill, install the remaining self-tapping screws.

