



ICON Golf Cart **Inner Basket**

Includes: Inner Basket & Mounting Hardware



Note: This installation method uses 4 self tapping screws. Your hardware kit may have additional hardware that will not be used in this install.

Step 1: Align basket roughly 1 inch above existing nuts that hold the windshield in place. Using a Clamp hold the basket in place and repeat on the opposite side. make sure the basket is level and Aligned at a comfortable position. **Do not remove the bolts (existing hardware) from the windshield.**



Step 2: Using a 8mm socket & drill, install one self-tapping on each side of the basket.

Step 3: Using a 8mm socket & drill, install the remaining self-tapping screws.



Using a 8 mm socket, tighten the nuts that hold the basket/windshield in place. **Use caution not to over.**

Call us: 877-564-5060