

Revenge Nerf Bar Installation Guide

Part Number: NB-704-IC

Fits: 2024 and Older ICON i60L Models

Instructions:

1. Locate the bracket area under your cart and identify the tabs.
(Image 1 shows the tab that needs to be removed.)
2. Remove the tab as shown. (Image 2)
3. View of the removed tab. (Image 3)
4. Drop bolts with washers from the top down. (Image 4)
5. Perform this step for both front and rear brackets on each side. (Image 5)
6. Install bracket along with washers and nuts. Do not fully tighten yet. (Image 6)
7. Both front and rear brackets installed. (Image 7)
8. Install the nerf bar step. Once complete, go back and tighten all bolts. (Image 8)















